



Fitting a Roller Blind inside the recess

This article refers to inside the recess only

1. Before fitting your roller blind always place the blind into the recess to check that the measurements are all correct.

For a roller in a recess we recommend you fix back to the frame for an easier and cleaner fit.

2. Place your brackets flush with the wall and flush to the back of the window and mark with a pencil the bracket holes to ensure a place to drill.

3. Once you have marked everything up pilot some holes for the fixings into the window frame where you marked the bracket holes.

4. When done you should be able to secure the bracket. Now repeat for the other side, make sure you have the right brackets on the right sides the cross bracket is where the controls are to be.

5. Once all the fixings have been screwed in its time to place the blind in the brackets. When hanging your roller blind make sure you push the sprung pin side in place first and then slot in the control end and ensure that it is secure.

6. Now you have fitted your roller blind just pull the chain to test it going up and down.

7. **Child safety is the most important part of fitting, so check your product for the instructions on how and where to fit the device.**

Child Safety design may vary please refer to our child safety device page.

