



## Fitting a Roller Blind outside the recess

This article refers to outside the recess only.

1. Before fitting your roller blind check that the measurements are correct with the window for outside the recess.

Fixing back to the wall is recommended when outside of the recess.

2. Place your brackets flat with the wall and mark with a pencil the bracket holes to ensure a place to drill.

3. Once you have marked everything up its time to locate an appropriate drill bit that can accommodate a rawlplug, start to drill the marked holes and then place a rawlplug in to the hole making sure it is tight and secure

4. When done you should be able to secure the bracket. Now repeat for the other side, make sure you have the right brackets on the right sides the cross bracket is where the controls are to be.

5. Once all the fixings have been screwed in its time to place the blind in the brackets. When hanging your roller blind make sure you push the sprung pin side in place first and then slot in the control end and ensure that it is secure.

6. Now you have fitted your roller blind just pull the chain to test it going up and down.

7. Child safety is the most important part of fitting, so check your product for the instructions on how and where to fit the device.

Child Safety design may vary please refer to our child safety device page.

