



Fitting a Wooden Venetian Blind outside the recess

This article refers to outside the recess only.

1. Before fitting your roller blind check that the measurements are correct with the window for outside the recess.

Fixing back to the wall is recommended when outside of the recess.

2. Place your brackets to where you wish them to be, then with a pencil carefully mark the bracket holes to give yourself a spot to drill for the fixings. You don't want to go too far above the top recess.

3. Once you have marked everything up drill into the wall for the fixings of the bracket. Once you have drilled into the marked areas place a rawlplug in each hole.

4. When done you should be able to secure the bracket. Now repeat for the other side. For longer width venetians we recommend you top fix a middle bracket fix it closer to the control side so that you have more security on that side of the blind.

5. Once all the fixings have been screwed in it's time to place the blind in the brackets. When hanging your venetian blind open the bracket doors and then slot the blind in and clip the doors shut.

6. Now you have fitted your venetian blind just pull the single cord to test it going up and down and then test the other two chords to test the open and close of the slats. Please refer to our pelmet section for help on the final stage.

7. **Child safety is the most important part of fitting, so check your product for the instructions on how and where to fit the device.**

Child Safety design may vary please refer to our child safety device page.

